Update Instructions for Intel® Platform Monitoring Technology Driver

[Precaution]

Before updating Intel® Platform Monitoring Technology (PMT) driver, you should
- Sign in as the administrator account.
- Connect AC Adaptor and fully charged battery.

[Summary of installation procedure]

1. Confirm the version of PMT driver
2. Extract the program for updating PMT driver
3. Update PMT driver

KEEP THESE STEPS STRICTLY, OR MALFUNCTION MAY BE CAUSED.

[Procedure]

1. Confirm the version of PMT driver

(1) Right click or touch and hold [Start] button to open the menu.
(2) Choose [Device Manager].
(3) Double click [System devices].
(4) Double click [Intel(R) Platform Monitoring Technology (PMT) Driver].
(5) Select [Driver] tab, and check "Driver Version".
If the version of the driver is older than "3.2.0.22" (e.g., 3.1.2.2 or 3.1.2.6), please execute step2.

2. Extract the program for updating PMT driver

(1) Double click the program named "PMT_3.2.0.22.exe".
(2) Click [Yes] if "User Account Control" window appears.
(3) Read the "License Agreement", and click [Yes].
(4) Confirm the destination folder
(default folder is "c:\util2\drivers\PMT_3.2.0.22"), and click [OK].
(5) Wait until files are extracted. The folder in which update files are extracted will be automatically opened on completion. It may take more than 1 minute until the folder appears.

3. Update PMT driver

(1) Right click or touch and hold [Pinstall] (In the case of setting to display extension, [Pinstall.bat]) and click [Run as administrator].
(2) Click [Yes] if "User Account Control" window appears.
(3) Wait until "C:\windows\System32\cmd.exe" window disappears. It may take more than several minutes until the window disappears.

[CAUTION]

Please do not click or touch "C:\windows\System32\cmd.exe" command prompt window until it disappears automatically. If inside of the window is clicked or touched, the command prompt will get into an edit mode, which suspends the bat execution.
If it gets into the edit mode, white cursor appears as in figure below. In this case, please

right click or touch and hold the inside of the window to get out of the edit mode. Then bat execution will be resumed. Please wait until the window disappears automatically.



(4) Restart the computer.
(5) Confirm the version of PMT driver is "3.2.0.22", with the same procedure as step1.